# FLIR KF6

Mountable Thermal Imaging Cameras for Aerial Firefighting Apparatus



# A New TIC Vantage Point

FLIR's new KF6 is the first mountable OEM thermal imager designed specifically for aerial apparatus applications. Providing a high-angle thermal view of rooftops and other elevated structures, KF6 can help your team see clearly through thick smoke from an additional strategic perspective to more efficiently target the hottest areas and direct firefighting efforts.







## **Aerial Mounting Flexibility**

The KF6 can be easily and securely fixed-mounted under or atop aerial platforms and at the end of straight sticks. A single cable with a MIL-C connector provides 10-32 VDC in and composite video out for simple installation.

#### **Best Resolution Shows You More**

Featuring 640 × 480 IR resolution and a 69° FOV, bolstered with onboard FSX™ Flexible Scene Enhancement, the KF6 produces vivid thermal images, providing finer detail and greater visibility for easier orientation and structural identification.

## **Convenient Monitoring**

Pair the KF6 with your preferred video display with one cable and view live, high-angle thermal video on a monitor at the turntable level, on an in-truck LCD, or on a screen right at the platform itself. Or connect to multiple displays via wireless systems.\*

# **CDMQ** Ruggedness

FLIR built the KF6 to our Commercially Developed Military Qualified standards. With a rugged housing that meets MIL-STD-810G, an IP67 rating, and extensive IEC testing, KF6 is ready to withstand harsh fire scene operating conditions, well-protected from exposure to heavy smoke and spray.

\* Monitors and wireless systems not included with KF6.

For more information on FLIR's firefighting thermal imaging cameras, please visit www.flir.com/fire.

USA Corporate Headquarters FLIR Systems, Inc. 27700 SW Parkway Ave. Wilsonville, OR 97070 USA TEL: +1 866.477.3687

EUROPE FLIR Commercial Systems Luxemburgstraat 2 2321 Meer Belgium TEL: +32 (0) 3665 5100 ASIA FLIR Systems Co. Ltd. Room 1613–16, Tower 2 Grand Central Plaza, No. 138 Shatin Rural Committee Road Shatin, New Territories Hong Kong TEL: +852 2792 8955

LATIN AMERICA FLIR Systems Brasil Av. Antonio Bardella, 320 Sorocaba, SP 18052-852 Brasil

TEL: +55 15 3238 7080

For a complete list of FLIR offices, please visit flir.com

NASDAQ: FLIR

