Why test portable gas detectors one by one, by one, by one, when you can test 4 at once?



Reduce testing time and gas usage with our portable or wall mountable MGC Dock.

You can keep testing your multi gas detectors one at a time, or you can test them all in no time, when you use ultra-reliable Multi Gas Clip (MGC) portable gas detectors, from Gas Clip Technologies, together with the MGC Dock or MGC Wall Mount Dock.

Accurately test and record all data for each monitor.

You name it, and the MGC Docks can do it. They accurately test, record and store information that is critical to maintain safety in your company. They provide individual monitor event logs, firmware, unit configurations and, of course, bump/calibration logs. The robust 4+ GB USB gives you all the memory you need and the lithium ion battery ensures thousands of tests before needing to be recharged.



Test 4 detectors at a time, up to 12 per minute!

Our MGC Docks let you bump test and calibrate 4 detectors at once for LEL, H_2S , CO and O_2 . With one dock, you can bump test up to 12 detectors in a minute, which saves valuable time and reduces the use of testing gas. The MGC Dock, or MGC Wall Mount Dock, is compatible with all Multi Gas Clip detectors (Infrared or Pellistor).

Call today, or visit www.gascliptech.com.

These reliable portable multi gas detectors and docks are proven to help facility workers and contractors do their jobs safely, productively and cost effectively. To learn more about the MGC Dock, MGC Wall Mount Dock and the unmatched dependability of the Multi Gas Clip, call or visit our website. Every second counts.



MGC Dock Quick Start Guide

MGC Dock



MGC Wall Mount Dock

Distributed By:

Specifications

Size

20" x 16" x 7.5" (50.8 x 40.6 x 19.05 cm)

Wall Mount 17.75" x 12" x 6.5" (45.2 x 30.5 x 16.5 cm)

Warranty

2 Years

Battery Type

Rechargeable Lithium Ion 2 months @ 100 instrument

bump tests/day

Memory

USB 4+ GB Standard

Tests Performed

Bump Test and Calibration

Certifications & Approvals

C EN 61326-1:2006

Information

Stored

Bump/Cal Logs, Individual Monitor Event Logs, Firmware and Unit Configurations

Gases Available

LEL, H₂S, CO and O₂

Unit Compatibility

Works with all MGC monitors

Calibration Gas

Compatible with 58L or 116L cylinders. Docks also available in a High Volume/High Pressure

model.



Portable gas detectors you can count on.

ww.gascliptech.com

Toll-free: 877.525.0808 2010-2014© Gas Clip Technologies, Inc. All Rights Reserved.